

CD900 Series Cabling Instructions



Below are the cabling instructions for the CD900 Series UHF CB Antennas.
This covers the following models:

- CD950-71-75
- CD951-71-75
- CD953-71-75
- CD960-71-75
- CD961-71-75
- CD963-71-75

1. Insert cable assembly through bottom of the base stud and pull cable through so it can be worked on.
2. Removed the outer jacket of cable to the length shown in Figure 1.
3. Trim braid to length as shown in Figure 2 and spread the braid each side as in Figure 3.
4. Twist the braid end symmetrically around the dielectric as shown in Figure 3/4.
5. Trim the dielectric to expose 9mm of inner conductor as in Figure 4.
6. Apply Loctite 262 to top thread where shown.
7. Slide the top assembly over the inner conductor and screw down tightly as in Figure 5.
8. The centre conductor should now appear out of the top of the whip stud.
9. Trim centre conductor if necessary and solder to the top stud.
10. Screw on whip.

